
















## Accessories

The following items are included with this machine. Check that all items are present.

|  |  |  |  |   |   |  |   |
|--|--|--|--|---|---|--|---|
| <br>Power cord (1)  | <br>Blade holder, blade, Pin (1 each) | <br>Media flanges (2),<br>Media bar (1), Mounting pin (1) | <br>USB cable (1)       | <br>Wiper (1)                            | <br>Jig for inserting cartridges<br>(1) ** | <br>SOL INK cleaning cartridge (1)** and<br>dummy cartridge(4) **     | <br>Software RIP***(1) |
| <br>Cleaning sticks | <br>Tweezers (1)                      | <br>Felt wiper (1)  | <br>Cleaning fluid (1) ** | <br>Inkjet printer maintenance guide (1)** | <br>Operation manuals (4)*                 | <br>Label for cartridge slot (one<br>each for ECO-SOL MAX and<br>FPG) |   |

\* To Ensure Safe Use: "First Step Guide" (this document), "MASTER GUIDE", "BN-20 VersaWorks Metallic Silver Ink Guide"

\*\* Included only in ECO-SOL MAX ink type machines, \*\*\* Roland VersaWorks (with Quick Start Guide)



RT-110607  
<http://www.rolanddg.com/>  
 Copyright © 2011 Roland DG Corporation

Company names and product names are trademarks or registered trademarks of their respective holders.

RolandDG Corp. has licensed the MMP technology from the TPL Group.

This product is using GNU General Public License (GPL) / GNU Lesser General Public License (LGPL) software. You have the right to acquire, modify, and distribute the source code for this GPL/LGPL software. You can obtain the GPL/LGPL source code used in this product by downloading it from the following website:  
 URL: <http://www.rolanddg.com/gpl/>

- Thank you for purchasing this product.
- To ensure safe use of this product and to thoroughly familiarize yourself with its performance, be sure to read this operation manual and store it for future reference.
  - Unauthorized copying or transfer, in whole or in part, of this manual is prohibited.
  - The contents of this document and the specifications of this product are subject to change without notice.
  - The documentation and the product have been prepared and tested as much as possible. If you find any misprint or errors, please inform us.
  - Roland DG Corp. assumes no responsibility for any direct or indirect loss or damage which may occur through use of this product, regardless of any failure of this product.
  - Roland DG Corp. assumes no responsibility for any direct or indirect loss or damage which may occur with respect to any article made using this product.

**Important**  
**Leave the main power switched on at all times.**  
 Never switch off the main power. By switching on the main power, the automatic maintenance function is carried out periodically. If the automatic maintenance is not carried out, it may result in a machine breakdown, e.g. damage to the print heads.

**Never switch off the main power or unplug the power cord during operation.**  
 Switching off the main power or unplugging the power cord during operation may damage the print heads. Be sure to first switch off the sub power. If the main power is accidentally switched off, immediately turn the main and sub power back on.

**Periodic use of the machine is recommended.**  
 We recommend using the machine at least once a week. If left unused for a long period of time, the ink may settle, resulting in unstable discharge (and dot drop-out). Any dry ink will need to be discharged.

**Allow the ink to dry completely.**  
 After output, allow the ink to dry completely. In particular, metallic silver ink must be printed with a high concentration and takes longer to dry than CMYK ink.

**Lamination of metallic silver ink is strongly recommended.**  
 Because metallic silver ink may not be as weather resistant as CMYK ink, depending on conditions, we strongly recommend laminating output of metallic silver ink.

# VersaSTUDIO

SIGN MAKER BN-20

## First Step Guide

Note : Please read accompanying sheet "To Ensure Safe Use" beforehand.

Roland DG Corporation

Thank you very much for purchasing the BN-20.  
 This document describes the procedure of "First Time Printing and Cutting," from installation and setup of this machine to the actual printing.

### About Roland OnSupport

Using OnSupport allows you to receive your printer's ink status and error information as an email sent to your PC and mobile phone. You can also receive product updates and other support information from OnSupport.

To install OnSupport, download from the following URL:  
[http://download.rolanddg.jp/en/bn\\_onsupport.html](http://download.rolanddg.jp/en/bn_onsupport.html)

Imagine.

## STEP 2: Making Adjustments Before Output

Before output, perform printing tests and test cuts, and make the necessary adjustments. This is required to make the most of BN-20's printing and cutting capabilities. Perform this task before daily operations and when changing the media type.


### Important

The components of the metallic silver ink can separate easily, so gently shake this ink cartridge each day before operations. The other color cartridges do not have to be shaken each day, but be sure to shake them when replacing. Failure to shake the ink

### 1. Starting the adjustment

- 1 Click  in the computer's task tray.


The BN-20 utility is displayed.



- 2 In the [Adjust All] tab, click [Adjust All].

- 3 Click [Next] on the displayed screen.


### 2. Check for nozzle clogging



Click [Test Print].  
The test pattern is printed.  
Follow the on-screen instructions to check for nozzle clogging.

Nozzle is clogged ⇨ Proceed to **2**.  
Nozzle is not clogged ⇨ Proceed to **4**.

Select [Normal Cleaning] and click [Go].  
Normal cleaning starts.




- 3 To check for nozzle clogging again ⇨ Return to **1**.

If the nozzle clogging is not fixed, perform "Normal Cleaning" again. For information about "Medium Cleaning" and "Powerful Cleaning," refer to pages regarding maintenance in "BN-20 Master Guide."

- 4 Click [Next] on the displayed screen.

### 3. Bidirectional adjustment



Click [Test Print].  
The test pattern is printed.

- 2 Read the on-screen instructions and then enter a value in the [New Value] box.

- 3 Click [Apply].

The value in [Present Value] changes to the entered value.

- 4 Click [Close].

- 5 Click [Next] on the displayed screen.

## STEP 3: Output Printing & Cutting Data

This section describes how to output printing and cutting data using R-Works.

- 1 From the Start menu, click [Programs] (or [All Programs]) > [R-Works] > [R-Works] > [R-Works].  
R-Works starts.

- 2 Click [Help] > [Table of Contents].


"R-Works Help" is displayed.



- 3 From the contents on the left, click [Operation Procedures].

Follow the instructions from "Introduction" to "Step 4: Output the data" to perform each operation and test the output of printing and cutting.

### 4. Media feed correction



Click [Test Print].  
The test pattern is printed.

- 2 Read the on-screen instructions and then enter a value in the [New Value] box.


- 3 Click [Apply].

The value in [Present Value] changes to the value entered.

- 4 Click [Close].

- 5 Click [Next] on the displayed screen.

### 5. Adjusting cutting



Click [Test Cut].  
Test cutting is performed.

- 2 Read the on-screen instructions and then enter values in the [Cut Force] box.


- 3 Click [Apply].

Repeat **1** **2** **3** until adjustment is done to allow the two shapes to peel off separately.

- 4 Click [Close].

- 5 Click [Next] on the displayed screen.

### 6. Adjusting printing & cutting



Click [Print and Cut Pattern].  
The test pattern is printed.

- 2 Follow the on-screen instructions and enter the values for [New Value for Scanning] and [New Value for Feeding].

- 3 Click [Apply].

The values in [New Value for Scanning] and [New Value for Feeding] change to "0."

- 4 Click [Close].


- 5 Click [Skip] on the displayed screen.

"Crop cut adjustment" will not be done here. It is not necessary for printing and cutting.

- 6 Click [OK] on the displayed screen.

Adjustment is completed.

Cutting off the media  
Use a commercially-available utility knife to cut the media.



## Installation


### Installation Location

#### Temperature and Humidity

Maintain the specified temperature and humidity even when the machine is not in use. If temperatures are too high or too low, it may cause the machine to malfunction.

- During operation: Temperature 20 to 32°C (68 to 90°F), relative humidity 35 to 80% (no condensation)
- During non-operation: Temperature 5 to 40°C (41 to 104°F), relative humidity 20 to 80% (no condensation)

#### Installation Space



Provide space as shown in the figure on the left.

#### Height of Installation

The height of installation should be 0.6 m (23.7 in.) or higher above the work floor. This machine is desktop type. Please decide the height of installation so that you can easily reach the emergency stop button when operating this machine.

## Installing and Setting Up the Software

| System requirements    |  |
|------------------------|--|
| Operating system       | Windows XP/Vista/7 (32- or 64-bit)                           |
| CPU and RAM            | CPU of 2.0-GHz or faster Core 2 Duo, and RAM of 2 GB or more |
| Optical drive          | CD-ROM drive   |
| Video card and display | Recommended: 1024 x 768 dots or higher, 256 colors or more   |

For the latest information, see the Roland DG Corp. website (<http://www.rolanddg.com>).

- This software is a 32-bit application and uses WoW64 (Windows 32-bit On Windows-64) when run on a 64-bit Windows system.
- Operations have not been confirmed in Windows XP mode.

## 1. Installing the software

- ➊ Insert the Roland Software Package CD-ROM into the computer.

Windows Vista or 7 : When the automatic playback window appears, click [Run Setup.exe].



- ➋ Click [Install] for either "Driver & Utility" or "R-Works."

The order of the installation is not important.

Windows Vista or 7 : When the [User Account Control] appears, click [Allow] or [Yes].


#### Driver & Utility

Installs the BN-20 driver and utility software.



Select [Install], Model name [Roland BN-20], Port [USB], and then click [Start].

Installation of the BN-20 driver starts. Proceed with the installation by following the on-screen instructions.




#### Windows Vista / 7 :

If the screen shown in the figure appears, click [Install this driver software anyway].

#### Windows XP :


If the screen shown in the figure appears, click [Continue Anyway].



After completing the installation of the driver, continue to install the utility software. When the screen shown on the left appears, the installation is complete.

#### R-Works

Installs R-Works.



Proceed with the installation by following the on-screen instructions. When the screen shown on the left appears, the installation is complete.

- ➌ Remove the Roland Software Package CD-ROM from the computer.

### Removing and storing the retainer


#### ⚠WARNING

Carry out these operations before you connect the power cord.

Inadvertent powerup may result in pinched hands or other injury.

- Be sure to remove the retainer. Failure to do so may cause faulty operation or breakdown when the power is switched on.

- The retainer is required when moving the machine to a different location. Store it carefully so that it does not get misplaced.




### Connecting the Power Cable

#### ⚠WARNING

Perform this task with all power switches left switched off.

Otherwise sudden movement of the machine may cause injury.



## 2. Setting up the printer

- ➊ Place the label for the ink type that will be used.

Mixing different types of ink may cause a malfunction. Please make sure to affix this label.




- ➋ Close the front cover, press ➀ Main power, and then press ➁ POWER key.

When the POWER key indicator changes from flashing to steady, startup is completed.

Connect the machine to the computer by USB cable.

Use the supplied USB cable.

Do not use a USB hub.




#### Windows Vista / 7 :

The driver is installed automatically. Go to Procedure ➋.


#### Windows XP :



Select [No, not this time], and then click [Next].



Select [Install the software automatically], and then click [Next].



Click [Finish].



Select [No, not this time], and then click [Next].

Select [Install the software automatically], and then click [Next].

- \* When having difficulty pulling out the dummy cartridges which is used for filling with ink, insert the Jig for inserting cartridges into the slots to make the task easier.

When the message of "The ink tanks have been filled" appears, filling with ink is completed. Click [Close], and then continue to "Printing and Cutting for the First Time" on the back.



# Printing and Cutting for the First Time

## STEP 1: Installing the Blade and Roll Media

Prepare roll media for printing and cutting that meets the following criteria:

➤ Width: 150 - 515 mm (5.9 - 20.27 in.). Paper tube inner diameter: 3 or 2 inches.

\*In this manual, the paper wound onto the paper tube is called "roll media."

\* To purchase these media, contact your authorized dealer or Roland DG.

### 1. Installing the Blade

- 1 Insert the pin into the blade holder. Insert until the tip protrudes about 3 - 5 mm (0.12 - 0.20 in.).
  - 2 Insert the blade.
- 
- Open the front cover.  
Loosen the screw shown in the figure.

\* For detailed information about how to install sheet media, such as standard-sized media, and usable media for this machine, refer to "BN-20 Master Guide."

- 3 Support the screw from below and insert the blade holder. Installing it without supporting the screw from below can adversely affect the cutting quality.
- 4 Tighten the screw. Tug the blade holder upward to make sure it does not come loose.

**Important Note on the Handling and Use of the Cutting Carriage**  
Leave the cutting-carriage screw loose when no blade holder is installed. Keeping the screw tightened causes the blade-holder insertion hole to become gradually smaller, making installation difficult.

### 2. Loading the Roll Media

- 1 Push the loading lever backward.
  - 2 Move the left media guide to the left.
- 
- Media bar  
Mounting pin  
Hole  
Media flange
- 3 Push in  
Make sure that there are no gaps.

Insert the side of the media bar with a hole into the media flange, and secure it with the mounting pin. Use one of the two media flanges. The inside should be the one that fits the inner diameter of the roll media paper tube.

- 4 Media feeding direction  
Media bar  
Unit
- Place the fixed media flange at the bottom, so that the media feeds in a clockwise direction when looking from above. You cannot set the media correctly if the feed direction is not right.

- 5 Move the roll media to the right so the media flange touches the right media guide.
  - 6 Slide the left media guide and press it to the media flange.
- 
- Media flange  
Right media guide

Pull the media straight to keep it taut, and let it pass beneath the media clamps.

- 7 Make sure the left media guide is pressed against the media flange.
  - 8 Pull the loading lever forward.
- 
- OK  
NG  
Media clamp

- 9 Close the front cover.
- Initialization starts when the front cover is closed and the loading lever is raised. Initialization is complete when the POWER key stops flashing and remains lit.

